

# ASSEMBLY INSTRUCTIONS

## VarioScreen for BMW R1200GS

***Thank you for purchasing an  
MRA protective screen.***

***Read these instructions carefully  
before installing the screen.***

***We recommend that you have the screen fitted by an authorized dealer.***

### **Installation:**

1. The protective screen is fitted the same way as the original part.
2. Unscrew the fastening screws of the original screen. Unscrew the adjusting screws on the sides by hand, the fastening screws using a Torx screwdriver.
3. Now remove the screen.
4. Remove the plastic bushings from the original screen by carefully wedging a knife underneath the edge and levering them out.
5. Insert the plastic bushings into the exact same position in the MRA screen. Make sure you do not swap the one on the right-hand side for the left and vice versa. Place the plastic washers included in the set under the bushings on the inside, one on the right, one on the left.
6. Fit the MRA screen with the original screws.
7. We recommend you start out with a flat setting when finding an ideal screen position. You may experience turbulence if the screen is set too steep.

**Make sure the screws are fastened tight immediately after fitting and at regular intervals after that. Tighten them up if needed.  
Clean the screen with neutral soap. Solvents, alcohol, and white spirits will damage the screen.**

***We wish you a safe, fun ride, and thank you for choosing our product.***