



**TWISTED  
THROTTLE**.COM

*Bolt-On Touring Accessories that fit YOUR motorcycle!*

## Fit Adjustment Kit Bags-Connection Quick-Lock Tankbags

TWT.TRT.00.005.100 Rev: 00

### Mounting Instructions

TWISTED THROTTLE products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. TWISTED THROTTLE takes no responsibility for damages caused by improper installation.

All screws, bolts, and nuts, including all replacement hardware provided by TWISTED THROTTLE should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M5.....3.5 ft-lbs (5 Nm)

All screws, bolts, and nuts should be checked after driving the first 30 miles (50 km) to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts, and nuts.



Included is two 1/2" (12.7mm) tall M5 spacers and two M5x30mm lenshead screws.

Insert between the front or rear mounting points of a Quick-Lock top ring and the tankbag to alter the angle at which the tankbag is attached to the bike.

#### Examples:

Honda ST1300 - insert under rear mount points for City or GS tankbag

Kawasaki GTR1400 Concours - insert under the front mount points to allow the front end of the tankbag clear the "hump" on the gas tank

Twisted Throttle LLC  
1080 Kingstown Rd, Building 1  
Peace Dale, RI 02879

phone: 401.284.4200  
fax: 401.223.6955  
www.twistedthrottle.com